

CREATOR KIT INSTRUCTIONS



more info

pkdsn.com/creatorkit

GET TO KNOW YOUR MOUNT

requires Peak Design Case
not included

SlimLink™
Mount Head

Locking
Teeth

Creator Kit
Arm

Release Button x2
You only have to press
one to release phone!

Thumbscrew



Arca
Adapter



Stabilizer
Screw

1/4"-20
Adapter



ARCA INSTALLATION



1. Connect **Creator Kit Arm** to provided **Arca Adapter**, affix with provided **Thumbscrew**.

2. Attach plate to any Arca compatible tripod, including Peak Design Tripods.

GOPRO INSTALLATION



1. Tighten **Creator Kit Arm** directly to any 3rd-party GoPro mount using provided **Thumbscrew**.

CAPTURE INSTALLATION



1. Connect Creator Kit Arm to provided Arca Adapter, tighten with Thumbscrew.



2. Slide Arca Adapter into Capture. Attach phone to SlimLink™ Mount Head in landscape mode. If needed, tighten Stabilizer Screw to eliminate play.

1/4"-20 INSTALLATION



1. Install Creator Kit Arm to provided 1/4"-20 Adapter.



2. Connect Creator Kit to 1/4"-20 screw.

USE



Attach/Detach Phone
Requires Peak Design Case (sold separately).

Place phone on mount and listen for audible "click" to ensure your phone is locked. To remove, push just one of the Release Buttons and pull phone.



Rotate
Use the provided Thumbscrew to adjust Creator Kit Arm angle.